

RHINO-RACK


QMFK18

Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.

*Note: RLT600 Parts as separate.

- Remove roof plugs.Apply Butyl Patches to Bracket.
- Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Item	Components	Qty	Part No.
1	Rubber Skirt - High	2	M829
2	M6 x 16mm SHCS	4	B031
3	M6 Spring Washer	4	W004
4	M6 x 12.5mm Flat Washer	4	W003
5	Bracket	2	CA1697
6	Butyl Patch	6	CA1397
7	Instruction	1	R1137



Issue 2: 26 Sept 2018 Document No: R1137

RHINO-RACK


QMFK18


Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.

*Note: RLT600 Parts as separate.

- Remove roof plugs.Apply Butyl Patches to Bracket.
- Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Item	Components	Qty	Part No.
1	Rubber Skirt - High	2	M829
2	M6 x 16mm SHCS	4	B031
3	M6 Spring Washer	4	W004
4	M6 x 12.5mm Flat Washer	4	W003
5	Bracket	2	CA1697
6	Butyl Patch	6	CA1397
7	Instruction	1	R1137





Document No: R1137

ONTROLLED




RHINO-RACK

QMFK18

Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.

- *Note: RLT600 Parts as separate.
- Remove roof plugs.
- Apply Butyl Patches to Bracket.
- Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Item	Components	Qty	Part No.
1	Rubber Skirt - High	2	M829
2	M6 x 16mm SHCS	4	B031
3	M6 Spring Washer	4	W004
4	M6 x 12.5mm Flat Washer	4	W003
5	Bracket	2	CA1697
6	Butyl Patch	6	CA1397
7	Instruction	1	R1137



Document No: R1137

RHINO-RACK

QMFK18


Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.

*Note: RLT600 Parts as separate.

- Remove roof plugs.
- Apply Butyl Patches to Bracket.
- Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Item	Components	Qty	Part No.
1	Rubber Skirt - High	2	M829
2	M6 x 16mm SHCS	4	B031
3	M6 Spring Washer	4	W004
4	M6 x 12.5mm Flat Washer	4	W003
5	Bracket	2	CA1697
6	Butyl Patch	6	CA1397
7	Instruction	1	R1137

Issue 2: 26 Sept 2018



Document No: R1137



HINO-RACK

QMFK18

Issue 2: 26 Sept 2018

Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.


*Note: RLT600 Parts as separate.

- Remove roof plugs.

Issue 2: 26 Sept 2018

- Apply Butyl Patches to Bracket. - Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Item	Components	Qty	Part No.
1	Rubber Skirt - High	2	M829
2	M6 x 16mm SHCS	4	B031
3	M6 Spring Washer	4	W004
4	M6 x 12.5mm Flat Washer	4	W003
5	Bracket	2	CA1697
6	Butyl Patch	6	CA1397
7	Instruction	1	R1137



Document No: R1137

CONTROLLED RHINO-RACK

QMFK18

Please refer to 'Fit My Car' on the Rhino-Rack web site for comprehensive instructions on fitting racks to your vehicle.


*Note: RLT600 Parts as separate.

- Remove roof plugs.

Issue 2: 26 Sept 2018

- Apply Butyl Patches to Bracket.
- Fasten Bracket to roof.
- Attach Rubber Skirt to RLT600 base.
- Attach RLT600 Leg Kit as per instructions.

Components Rubber Skirt - High	Qty	Part No.
	2	M829
M6 x 16mm SHCS	4	B031
M6 Spring Washer	4	W004
M6 x 12.5mm Flat Washer	4	W003
Bracket	2	CA1697
Butyl Patch	6	CA1397
Instruction	1	R1137
	M6 x 16mm SHCS M6 Spring Washer M6 x 12.5mm Flat Washer Bracket Butyl Patch	M6 x 16mm SHCS 4 M6 Spring Washer 4 M6 x 12.5mm Flat Washer 4 Bracket 2 Butyl Patch 6



Document No: R1137